


B&K RJ45 - RS-232 PIN Description

(Rear view of B&K)



NC No Connection.

 RS-232 Host Receive.

 RS-232 Host Transmit.

 RS-232 Signal Ground.

DB9	DB25	FUNCTION	RJ45 CONNECTION
PIN 3	PIN 2	Host Transmit	to RJ45 RED
PIN 2	PIN 3	Host RECEIVE	to RJ45 GREEN
PIN 5	PIN 7	Host GROUND	to RJ45 BLACK

Radio Shack Cat No. 276-1406A(DB25F - RJ45) 8 Wire Modular/EIA Adapter Kit.
Host(PC) may then be connected to B&K via a straight passthrough "RJ" type cable.