

B&K CT/HD6 Hardware Quick Tools:

This is a small application that you can open on your PC, and "point & click" to operate basic functions of the HD6 and any CT Receiver. When using this application, connect your PC to the CT Receiver or HD6 Video Switcher in the same manner you would connect to BKCSuite. The controllable functions are:

1. Recieve Unit Infomation.
2. Turn on/off HD6 color bar test patterns.
3. Power on/off all zones in an HD6 or a CT Receiver.
4. Reset any unit.
5. Re-initialize BKC-Dip (serial) operation.
6. Select any input in the whole house.
7. Select any FM tuner frequency in the entire house.
8. Control the volume of the entire house.
9. Send any manually entered BKC-Dip Serial string.

The FM tuner/frequency selections provide the ability to troubleshoot audio related problems by using the internal tuner source. The FM frequency selection box is provided, so the installer has the ability to pick a strong FM station when troubleshooting audio related problems.

Installation is not required for the application. Just extract the file and copy the attached .exe file to your desktop, or an appropriate location. Click on the icon to launch the application.

This application is an extension of the BKCSuite. While this application will have it's own seperate icon on your desktop (if desired), you need BKCSuite, or Visual Basic, installed on your computer to run this application.

PJP 6/7/06